

Zubehör

Accessories

Mutterabdeckungen · Nut Coverings		Zeiger · Pointers	Zeigerscheiben · Pointer Dials		Grundplatten · Base Plates
ohne Zeiger without Pointer	mit Zeiger with Pointer				
■ 330.120	■ 330.130	■ 330.100 ■ 330.101 ■ 330.102	■ 330.250	A ... 330.200 B ... 330.201 C ... 330.202 D ... 330.203 E ... 330.204 F ... 330.205	■ 330.300
■ 331.120	■ 331.130 ■ 331.132	■ 331.100 ■ 331.101 ■ 331.102	■ 331.250	A ... 331.200 B ... 331.201 C ... 331.202 D ... 331.203 E ... 331.204 F ... 331.205	■ 331.300
■ 332.120	■ 332.100 ■ 332.101 ■ 332.102	■ 4332.100	■ 332.250	A ... 332.200 B ... 332.201 C ... 332.202 D ... 332.203 E ... 332.204 F ... 332.205	■ 332.300
		■ 333.100 ■ 333.101 ■ 333.102	■ 333.250	A ... 333.200 B ... 333.201 C ... 333.202 D ... 333.203 E ... 333.204 F ... 333.205	■ 333.300
					Feststeller · Arrestor
		■ 334.100 ■ 334.101 ■ 334.102		A ... 334.200 B ... 334.201	
					mit Anzeige with indication h = 7,5 329.15 h = 12 329.14 ohne Anzeige without indication h = 7,5 329.05 h = 12 329.04
		■ 335.100 ■ 335.101 ■ 335.102		A ... 335.200 B ... 335.201	